

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
000-10400	MHV	167	031-212-1005	BNC	111
000-11050	HN	154	031-212-RFX	BNC	111
000-12650	MHV	167	031-218	BNC	114
000-14000	Between Series Adapters	179, 180	031-218-75RFX	BNC	118
000-15875	BNC	111	031-218-RFX	BNC	114
000-16050	Between Series Adapters	180	031-219	BNC	114
000-16075	Between Series Adapters	180	031-219-75	BNC	118
000-18225	BNC	113	031-219-RFX	BNC	114
000-21900	BNC	115	031-220G-RFX	BNC	115
000-27000	MHV	167	031-220H	BNC	115
000-27025	MHV	167	031-220N	BNC	115
000-27075	MHV	166	031-220N-75	BNC	118
000-27975	MHV	166	031-220N-75RFX	BNC	118
000-28000	MHV	166	031-220N-RFX	BNC	115
000-28100	MHV	166	031-221	BNC	113
000-28175	MHV	166	031-221-75RFX	BNC	117
000-2900	Between Series Adapters	178, 179	031-221-RFX	BNC	113
000-29100	MHV	166	031-222	BNC	113
000-34025-536C	Type N	147	031-2221	BNC	113
000-34025-RFX	Type N	147	031-2300	TNC	125
000-35025-RFX	Type N	148	031-2300-RFX	TNC	125
000-35650-51	BNC	119	031-2315	TNC	124
000-35650-75	BNC	119	031-2315-RFX	TNC	124
000-36500-RFX	Type N	148	031-2318	TNC	125
000-36800	BNC	112	031-2318-RFX	TNC	125
000-36800-RFX	BNC	112	031-236	BNC	113
000-4400	Between Series Adapters	179, 180	031-2367	TNC	124
000-4500	BNC	112	031-2367-RFX	TNC	124
000-46650-51	BNC	119	031-2368	TNC	124
000-46650-51RFX	BNC	119	031-2368-RFX	TNC	124
000-46650-75RFX	BNC	119	031-2373	TNC	124
000-46650-93RFX	BNC	119	031-239	BNC	113
000-47000	BNC	115	031-242	BNC	110
000-49000-RFX	Type N	148	031-242-RFX	BNC	110
000-5275	BNC	119	031-28	Between Series Adapters	178, 179
000-6775	BNC	111	031-2-RFX	BNC	111
000-68175-1003	BNC	110	031-315	BNC	110
000-68175-1005	BNC	110	031-315-1005	BNC	110
000-68175-11RFX	BNC	110	031-315-RFX	BNC	110
000-68175-5RFX	BNC	110	031-316	BNC	110
000-69475	BNC	111	031-317	BNC	112
000-79125	TNC	126	031-318	BNC	112
000-79700	TNC	126	031-318-RFX	BNC	112
000-79875	TNC	124	031-320	BNC	110
000-79875-RFX	TNC	124	031-320-1006	BNC	110
000-86350	BNC	112	031-320-RFX	BNC	110
031-10	BNC	113	031-321	BNC	110
031-10152-RFX	BNC	119	031-321-1000	BNC	110
031-102	BNC	113	031-321-RFX	BNC	110
031-105	BNC	112	031-3220	BNC	115
031-10-75	BNC	117	031-325	BNC	110
031-10-RFX	BNC	113	031-326	BNC	110
031-15	BNC	112	031-326-RFX	BNC	110
031-17	BNC	119	031-3301	BNC	111
031-202	BNC	111	031-3302	BNC	111
031-203	BNC	112	031-335	BNC	110
031-203-RFX	BNC	112	031-335-RFX	BNC	110
031-206	BNC	112	031-336	BNC	110
031-207	BNC	112	031-336-RFX	BNC	110
031-208	BNC	115	031-3376	BNC	113
031-208-RFX	BNC	115	031-342	BNC	112
031-212	BNC	111	031-342-RFX	BNC	112

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
031-343-RFX	BNC	112	031-6006	BNC	110
031-4237	BNC	113	031-6009	BNC	117
031-4238	BNC	113	031-6032	BNC	115
031-4320	BNC	110	031-6034	BNC	115
031-4321	BNC	110	031-6035	BNC	115
031-4327	BNC	112	031-6036	BNC	115
031-4411	BNC	110	031-6055	Mini-BNC	103
031-4427	BNC	110	031-6055-1	Mini-BNC	103
031-4791	TNC	126	031-6101	Between Series Adapters	176, 179
031-4803-75	BNC	118	031-6109	Between Series Adapters	176, 179
031-4890-1	BNC	113	031-6112	Between Series Adapters	176, 179
031-5	BNC	112	031-6138	TNC	124
031-5136	BNC	111	031-6139	TNC	124
031-5136-RFX	BNC	111	031-6140	TNC	124
031-5137	BNC	111	031-6141	TNC	124
031-5137-RFX	BNC	111	031-6142	TNC	124
031-5329	BNC	113	031-6143	TNC	124
031-5329-51RFX	BNC	113	031-6144	TNC	124
031-5329-52RFX	BNC	113	031-6145	TNC	124
031-5431	BNC	114	031-6146	TNC	124
031-5431-1010	BNC	114	031-6147	TNC	124
031-5431-10RFX	BNC	114	031-6148	TNC	124
031-5486	BNC	114	031-6149	TNC	124
031-5486-1010	BNC	114	031-6150	TNC	124
031-5486-10RFX	BNC	114	031-6151	TNC	124
031-5493	BNC	114	031-6152	TNC	124
031-5493-1010	BNC	113	031-6153	TNC	124
031-5538	BNC	114	031-6154	TNC	124
031-5538-1010	BNC	114	031-6156	TNC	124
031-5538-10RFX	BNC	114	031-6157	TNC	124
031-5539	BNC	114	031-6158	TNC	124
031-5539-1010	BNC	114	031-6159	TNC	124
031-5540	BNC	114	031-6160	TNC	124
031-5540-1010	BNC	114	031-6161	TNC	124
031-5556-RFX	BNC	111	031-6162	TNC	124
031-5557-RFX	BNC	111	031-6163	TNC	124
031-5558-RFX	BNC	111	031-6164	TNC	124
031-5559-RFX	BNC	111	031-6165	TNC	124
031-5607	TNC	126	031-6166	TNC	125
031-5633	BNC	113	031-6167	TNC	125
031-5633-1010	BNC	113	031-6168	TNC	125
031-5637	BNC	114	031-6169	TNC	125
031-5640	BNC	114	031-6170	TNC	125
031-5640-1010	BNC	114	031-6171	TNC	125
031-5660	TNC	126	031-6172	TNC	126
031-5663	BNC	119	031-6173	TNC	125
031-5684	TNC	127	031-6174	TNC	125
031-5705	BNC	115	031-6175	TNC	125
031-5787-T	BNC	115	031-6176	TNC	125
031-5800	BNC	110	031-6177	TNC	125
031-5849-RFX	TNC	124	031-6178	TNC	125
031-5900	BNC	110	031-6179	TNC	125
031-5998-RFX	BNC	110	031-6180	TNC	125
031-5999-RFX	BNC	110	031-6181	TNC	125
031-6	BNC	119	031-6197	TNC	126
031-6000-RFX	TNC	124	031-6198	TNC	126
031-6001-RFX	TNC	124	031-6199	TNC	126
031-6002-RFX	TNC	124	031-6200	TNC	126
031-6003-RFX	TNC	124	031-6201	TNC	126
031-6004-RFX	BNC	110	031-6202	TNC	126
031-6005-RFX	BNC	110	031-6203	TNC	126

Part Number	Series	Page	Part Number	Series	Page
031-6-RFX	BNC	119	031-71052-10RFX	BNC	117
031-5677-100	TNC	127	031-71053	BNC	117
031-5680	TNC	127	031-71053-1010	BNC	117
031-5685	TNC	127	031-71058	BNC	117
031-5686	TNC	127	031-71059	BNC	118
031-6030	TNC	127	031-71059-1010	BNC	118
031-6031	TNC	127	031-71062	BNC	117
031-6032	TNC	127	031-71063	TNC	126
031-6033	TNC	127	031-71065	BNC	116
031-6293	TNC	127	031-71066	BNC	116
031-70000	BNC	116	031-759	BNC	119
031-70008	BNC	116	031-80101	High Performance 75 Ω BNC	172
031-70008-3000	BNC	116	031-80102	High Performance 75 Ω BNC	172
031-70013	BNC	116	031-80103	High Performance 75 Ω BNC	172
031-70018	BNC	117	031-80104	High Performance 75 Ω BNC	172
031-70019	BNC	118	031-80105	High Performance 75 Ω BNC	172
031-70020	BNC	118	031-80106	High Performance 75 Ω BNC	172
031-70036	BNC	118	031-80107	High Performance 75 Ω BNC	172
031-70040-100T	BNC	117	031-80108	High Performance 75 Ω BNC	172
031-70221	BNC	118	031-80109	High Performance 75 Ω BNC	172
031-70234	BNC	116	031-80401	High Performance 75 Ω BNC	172
031-70235	BNC	116	031-80404	High Performance 75 Ω BNC	172
031-70236	BNC	116	031-80405	High Performance 75 Ω BNC	172
031-70237	BNC	116	031-80901	High Performance 75 Ω BNC	172
031-70238	BNC	116	031-80904	High Performance 75 Ω BNC	172
031-70239	BNC	116	031-80905	High Performance 75 Ω BNC	172
031-70240	BNC	116	031-9	BNC	115
031-70249	Mini-BNC	103	031-9-75	BNC	118
031-70250	Mini-BNC	103	031-9-75RFX	BNC	118
031-70251	Mini-BNC	102	031-9-RFX	BNC	115
031-70252	Mini-BNC	102	081-114-RFX	Mini-UHF	84
031-70253	Mini-BNC	102	081-115BK-1000	Mini-UHF	84
031-70255	Mini-BNC	103	081-115N-1000	Mini-UHF	84
031-70259	Mini-BNC	102	081-116	Mini-UHF	84
031-70260	Mini-BNC	102	081-118-1001	Mini-UHF	84
031-70261	Mini-BNC	102	081-120	Mini-UHF	84
031-70265	Mini-BNC	103	081-141-1002	Mini-UHF	84
031-70331	Mini-BNC	102	081-181-RFX	Mini-UHF	84
031-70332	Mini-BNC	102	081-182-RFX	Mini-UHF	84
031-70333	Mini-BNC	102	081-183-RFX	Mini-UHF	84
031-70334	Mini-BNC	102	082-100	Type N	149
031-70335	Mini-BNC	102	082-100-RFX	Type N	149
031-71000-RFX	BNC	116	082-101	Type N	149
031-71004	BNC	117	082-101-RFX	Type N	149
031-71008	BNC	116	082-102	Type N	149
031-71008-1000	BNC	116	082-202	Type N	147
031-71008-1RFX	BNC	116	082-202-1006	Type N	147
031-71008-2000	BNC	116	082-202-RFX	Type N	147
031-71008-RFX	BNC	116	082-213	Type N	149
031-71011-RFX	BNC	117	082-312	Type N	147
031-71013	BNC	116	082-3202	Type N	147
031-71013-RFX	BNC	116	082-332	Type N	147
031-71016-RFX	BNC	117	082-340	Type N	147
031-71032	BNC	116	082-340-1052	Type N	147
031-71033	BNC	116	082-346-RFX	Type N	148
031-71042	BNC	118	082-368	Type N	148
031-71043	BNC	117	082-4352	Type N	147
031-71043-1010	BNC	117	082-4425	Type N	147
031-71045-1010	BNC	117	082-4425-1003	Type N	147
031-71047-1010	BNC	118	082-4426	Type N	147
031-71052	BNC	117	082-4426-11RFX	Type N	147

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
082-4427	Type N	147	082-92	HN	154
082-4429-RFX	Type N	148	082-97	Type N	148
082-4440	Type N	147	082-97-RFX	Type N	148
082-4440-1001	Type N	147	082-99	Type N	149
082-4442	Type N	147	083-10	Between Series Adapters	179
082-504	C	132	083-168	UHF	139
082-515	C	132	083-168-RFX	UHF	139
082-209-1006	Type N	148	083-185	UHF	139
082-530	C	132	083-185-RFX	UHF	139
082-532	C	132	083-1AC	UHF	140
082-5370	Type N	147	083-1AC-RFX	UHF	140
082-5372	Type N	148	083-1AP	UHF	139
082-5373	Type N	148	083-1F	UHF	139
082-5374	Type N	147	083-1H	UHF	140
082-5375	Type N	147	083-1J	UHF	139
082-5375-RFX	Type N	147	083-1R	UHF	138
082-5376-RFX	Type N	148	083-1R-RFX	UHF	138
082-5378	Type N	148	083-1SP	UHF	138
082-5378-RFX	Type N	148	083-1SP-1050	UHF	138
082-5380-RFX	Type N	147	083-1SP-15RFX	UHF	138
082-5933	Type N	148	083-1SP-4051	UHF	138
082-5955-RFX	Type N	147	083-1SPB-15RFX	UHF	138
082-5956-RFX	Type N	147	083-1T	UHF	139
082-5988-1000	Type N	147	083-58FCP	UHF	138
082-5993	Type N	147	083-58FCP-RFX	UHF	138
082-5994	Type N	148	083-58SP	UHF	138
082-5995	Type N	147	083-58SP-1002	UHF	138
082-6034	Type N	147	083-59	UHF	138
082-6048-1000	Type N	147	083-59SP	UHF	138
082-6092-RFX	Type N	148	083-67	UHF	138
082-6093-RFX	Type N	148	083-765	UHF	140
082-6096-RFX	Type N	148	083-798	UHF	138
082-6097-RFX	Type N	148	083-822	UHF	138
082-6098-RFX	Type N	148	083-875	UHF	138
082-6099-RFX	Type N	148	083-875-1002	UHF	138
082-6100-RFX	Type N	148	083-877	UHF	139
082-6101-RFX	Type N	148	083-878	UHF	139
082-6106	Type N	147	083-878-RFX	UHF	139
082-6124	Type N	147	083-886	UHF	138
082-6142-1000	Type N	147	083-886-2050	UHF	138
082-6143-1000	Type N	148	083-8SP-RFX	UHF	138
082-6151-RFX	Type N	148	083-909	UHF	140
082-6152	Type N	147	083-910-RFX	Between Series Adapters	178, 179
082-6157	Type N	147	102-100-01	1.0/2.3	32
082-6158	Type N	148	102-233-01	1.0/2.3	31
082-6162	Type N	148	102-233-10	1.0/2.3	31
082-6163	Type N	148	102-233-20	1.0/2.3	31
082-62	Type N	148	102-233-30	1.0/2.3	31
082-63	Type N	148	102-243-41	1.0/2.3	30
082-63-RFX	Type N	148	102-245-01	1.0/2.3	31
082-6316	HN	154	102-245-10	1.0/2.3	31
082-64	Type N	149	102-245-20	1.0/2.3	31
082-64-RFX	Type N	149	102-246-41	1.0/2.3	30
082-66	Type N	149	102-246-85	1.0/2.3	30
082-66-RFX	Type N	149	102-692-01	1.0/2.3	32
082-804	HN	154	102-692-04	1.0/2.3	32
082-805	HN	154	102-692-10	1.0/2.3	32
082-816-1000	HN	154	102-799-04	1.0/2.3	30
082-843	HN	154	102-799-04DB	1.0/2.3	30
082-856	HN	154	102-799-050	1.0/2.3	32
082-91	HN	154	102-799-104	1.0/2.3	30

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
102-799-104DB	1.0/2.3	30	531-40103	Type F	90
102-799-116	1.0/2.3	30	531-40106	Type G	96
102-799-116DB	1.0/2.3	30	531-40119	Type G	96
102-799-141	1.0/2.3	30	531-40120	Type F	91
102-799-16	1.0/2.3	30	531-40131	Type G	96
102-799-16DB	1.0/2.3	30	531-40132	Type F	90
102-799-185	1.0/2.3	30	531-40135	Type F	90
102-799-41	1.0/2.3	30	531-40136	Type F	90
102-799-48	1.0/2.3	30	531-40144	Type F	90
102-799-85	1.0/2.3	30	531-40147	Type F	91
102-811-03	1.0/2.3	32	531-40148	Type F	91
102-909-02	1.0/2.3	32	531-40156	Type F	90
102-909-D100	1.0/2.3	32	531-40165	Type F	90
102-912-02	1.0/2.3	32	901-10003	SMA	71
102-912-10	1.0/2.3	32	901-10005	Between Series Adapters	176, 177
102-912-20	1.0/2.3	31	901-10006	Between Series Adapters	176, 177
102-913-06	1.0/2.3	30	901-10007	Between Series Adapters	176, 177
102-913-06DB	1.0/2.3	30	901-10008	Between Series Adapters	176, 177
102-913-07	1.0/2.3	30	901-10009-RFX	SMA	66
102-920-06	1.0/2.3	30	901-10010-RFX	SMA	66
131-91038	Between Series Adapters	177	901-10011	SMA	66
227-1221-11	Tools	190	901-10012	SMA	66
227-1221-13	Tools	190	901-10013-RFX	SMA	68
227-1221-15	Tools	190	901-10014	SMA	67
227-1221-23	Tools	190	901-10015	SMA	68
227-1221-25	Tools	190	901-10019	SMA	71
227-1221-29	Tools	190	901-10021-12SF	SMA	68
227-1221-3	Tools	190	901-10021-1SF	SMA	68
227-1221-32	Tools	190	901-10021-3SF	SMA	68
227-1221-37	Tools	190	901-1004-1RFX	SMA	71
227-1221-57	Tools	190	901-1004-2RFX	SMA	71
227-1221-59	Tools	190	901-1004-3RFX	SMA	71
227-1221-61	Tools	190	901-1004-4RFX	SMA	71
227-1221-9	Tools	190	901-10044-6RFX	SMA	71
227-1409	Tools	190	901-10097	Between Series Adapters	176, 177
227-1414	Tools	190	901-10107	AMC	5
227-1417	Tools	188	901-10110	SMA	71
227-1418	Tools	188	901-10111	SMA	71
227-1419	Tools	188	901-101-15	SMA	66
227-1420	Tools	188	901-10119	AMC	5
227-1448	Tools	190	901-10129	AMC	5
227-944	Tools	190	901-10186	SMA	71
227-980-1	Tools	190	901-103	SMA	66
227-980-2	Tools	190	901-103-11	SMA	66
227-980-3	Tools	190	901-125-11	SMA	72
227-980-7	Tools	190	901-125-11SF	SMA	72
227-987	Tools	188	901-128-11	SMA	66
531-40001	Type F	90	901-143	SMA	71
531-40008	Type F	91	901-143-3	SMA	71
531-40010	Between Series Adapters	178	901-143-4	SMA	71
531-40024	Type G	96	901-143-6RFX	SMA	71
531-40035-1006	Type F	90	901-144	SMA	70
531-40039	Type F	90	901-144-2	SMA	70
531-40046-1	Type F	90	901-144-3	SMA	70
531-40046-3	Type F	90	901-144-4	SMA	70
531-40047-3	Type F	90	901-144-8RFX	SMA	70
531-40047-4	Type F	90	901-144-PF8	SMA	71
531-40051	Type G	96	901-144-PFD	SMA	71
531-40065	Type G	96	901-148-15	SMA	67
531-40070	Type G	96	901-155-12	SMA	66
531-40101	Type F	90	901-155-16	SMA	66

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
901-168	Between Series Adapters	177, 179	901-9602-1SF	SMA	68
901-171	Between Series Adapters	177, 179	901-9602-3	SMA	68
901-178	SMA	72	901-9602-3SF	SMA	68
901-368-12	SMA	67	901-9610-12SF	SMA	68
901-382-1	SMA	72	901-9610-1SF	SMA	68
901-9023	SMA	69	901-9610-3	SMA	68
901-9033	Between Series Adapters	176, 177	901-9610-3SF	SMA	68
901-9034	Between Series Adapters	176, 177	901-9704	SMA	68
901-9038	Between Series Adapters	176, 177	901-9723	SMA	67
901-9201-1A	SMA	67	901-9723-10	SMA	67
901-9201-1ASF	SMA	67	901-9758	SMA	69
901-9201-2A	SMA	67	901-9767	SMA	69
901-9201-2ASF	SMA	67	901-9770	SMA	69
901-9202-1A	SMA	68	901-9789	SMA	69
901-9202-2A	SMA	68	901-9804-1	SMA	69
901-9204-CCSF	SMA	69	901-9805-HP	SMA	67
901-9209-A	SMA	72	901-9808	SMA	67
901-9209-ASF	SMA	72	901-9808-1	SMA	67
901-9210-1	SMA	68	901-9808-2	SMA	67
901-9210-2	SMA	68	901-9814	SMA	69
901-9211	SMA	69	901-9839	SMA	69
901-9214-CC	SMA	69	901-9841	SMA	69
901-9215	SMA	69	901-9850	SMA	71
901-9216	SMA	72	901-9852	SMA	71
901-9216-SF	SMA	72	901-9856	SMA	69
901-9217	SMA	72	901-9857	SMA	72
901-9217-SF	SMA	72	901-9863	SMA	72
901-9218	SMA	72	901-9864	SMA	72
901-9218-SF	SMA	72	901-9865	SMA	72
901-9220	SMA	69	901-9867-RFX	SMA	67
901-9221-1A	SMA	68	901-9868-RFX	SMA	67
901-9221-1ASF	SMA	68	901-9870	SMA	66
901-9221-2A	SMA	68	901-9871	SMA	66
901-9221-2ASF	SMA	68	901-9872	SMA	67
901-9244-1	SMA	69	901-9873	SMA	67
901-9244-1SF	SMA	69	901-9874	SMA	67
901-9501-3	SMA	66	901-9875	SMA	68
901-9511-1	SMA	66	901-9876-RFX	SMA	66
901-9511-12SF	SMA	66	901-9877-RFX	SMA	66
901-9511-12SFC	SMA	66	901-9879-RFX	SMA	68
901-9511-1SF	SMA	66	901-9880-RFX	SMA	67
901-9511-1SFC	SMA	66	901-9881-RFX	SMA	67
901-9511-2	SMA	66	901-9884	SMA	71
901-9511-2SF	SMA	66	901-9887-RFX	SMA	70
901-9511-3	SMA	66	901-9889-RFX	SMA	70
901-9511-3SF	SMA	66	901-9890-RFX	SMA	70
901-9511-3SFC	SMA	66	901-9891-RFX	SMA	70
901-9521-3	SMA	67	901-9892-RFX	SMA	70
901-9531-1	SMA	67	901-9893-RFX	SMA	70
901-9531-12	SMA	67	901-9894-RFX	SMA	70
901-9531-12SF	SMA	67	901-9895-RFX	SMA	70
901-9531-1SF	SMA	67	901-9908	SMA	71
901-9531-2	SMA	67	901-9911	SMA	69
901-9531-2SF	SMA	67	901-9916	SMA	66
901-9531-3	SMA	67	901-9990	SMA	72
901-9531-3SF	SMA	67	903-10408-1	SMB	43
901-9601-1SF	SMA	66	903-10408-1	SMC	57
901-9601-3	SMA	66	903-10409-1	SMB	43
901-9601-3SF	SMA	66	903-10409-1	SMC	57
901-9602-1	SMA	68	903-108J-71S	SMB	44
901-9602-12SF	SMA	68	903-152P-71S	SMB	44

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
903-152P-71S3	SMB	44	903-588P-71A	Mini 75Ω SMB	51
903-152P-71S7	SMB	44	903-598P-71S	Mini 75Ω SMB	51
903-284P-52S	SMC	56	903-599P-71A	Mini 75Ω SMB	51
903-284P-52S1	SMC	56	903-600P-71S	Mini 75Ω SMB	51
903-285P-51S	SMB	41	903-601J-71P	Mini 75Ω SMB	51
903-287P-51S	SMB	41	903-604J-71S	Mini 75Ω SMB	51
903-288P-52A	SMC	56	903-605P-71S	Mini 75Ω SMB	51
903-289P-51A	SMB	41	903-659J-51S	SMB	42
903-291P-51A	SMB	41	903-660P-71S	SMB	44
903-291P-51A1	SMB	41	903-662P-71A	SMB	44
903-305J-51R	SMB	42	903-663P-71S	SMB	44
903-362P-52A1	SMC	56	903-675J-71S	SMB	44
903-367P-51A	SMB	41	903-677P-71A	Mini 75Ω SMB	51
903-367P-51A2	SMB	41	908-21100	MMCX	17
903-368P-51A1	SMB	41	908-21100T	MMCX	17
903-369P-51A2	SMB	41	908-21102	MMCX	17
903-370P-51S	SMB	41	908-21103	MMCX	16
903-371P-51S	SMB	41	908-22100	MMCX	17
903-373J-51A	SMB	43	908-22100T	MMCX	17
903-375J-53P	SMB	43	908-22101	MMCX	17
903-376J-51A	SMB	43	908-22101B	MMCX	17
903-378J-52A	SMC	57	908-22101T	MMCX	17
903-382J-71R	SMB	44	908-22101-TC	MMCX	17
903-401P-51S	SMB	41	908-22103	MMCX	17
903-402J-51R	SMB	42	908-22106	MMCX	16
903-406J-51R	SMB	42	908-22109	MMCX	16
903-407J-51R	SMB	42	908-24100	MMCX	16
903-408J-52R	SMC	56	908-31100	Between Series Adapters	176, 177
903-409J-53P	SMB	43	908-32101	Between Series Adapters	176, 177
903-410P-53P	SMB	43	908-41000	AMC	5
903-413J-51A	SMB	43	908-41200	MMCX	16
903-415J-51P	SMB	43	908-41300	MMCX	16
903-416J-51R	SMB	42	908-41400	MMCX	16
903-419J-52A	SMC	57	908-41500	MMCX	16
903-420J-52P	SMC	57	908-41600	MMCX	16
903-421J-52P	SMC	57	908-42300	MMCX	16
903-422J-51A	SMB	42	908-42500	MMCX	16
903-422J-51A2	SMB	42	908-43001	AMC	5
903-429P-51A	SMB	41	908-43200	MMCX	16
903-499J-51P2	SMB	43	908-43300	MMCX	16
903-502P-71S	SMB	44	908-43400	MMCX	16
903-505J-51S	SMB	42	908-43500	MMCX	16
903-505J-51S1	SMB	42	908-43600	MMCX	16
903-509P-51S	SMB	41	919-101P-51S1X	MCX	23
903-515J-51P	SMB	43	919-101P-51SX	MCX	23
903-518J-51P	SMB	43	919-102P-51AX	MCX	23
903-518J-71P	SMB	45	919-103P-51AX	MCX	23
903-519J-71P	SMB	45	919-104P-51A1X	MCX	23
903-522P-71P	SMB	45	919-104P-51AX	MCX	23
903-523J-71P	SMB	45	919-107J-51S1X	MCX	23
903-574P-71S	SMB	44	919-107J-51SX	MCX	23
903-575P-71S	SMB	44	919-109J-51PX	MCX	23
903-577P-51S	SMB	41	919-114J-51SX	MCX	23
903-577P-51S1	SMB	41	919-118J-51P	MCX	23
903-578P-51S	SMB	41	919-119J-51AX	MCX	23
903-578P-51S1	SMB	41	919-120P-51SX	MCX	23
903-579P-51S	SMB	41	919-121P-51SX	MCX	23
903-579P-51S1	SMB	41	919-122P-51AX	MCX	23
903-581J-71P	Mini 75Ω SMB	51	919-129J-51SX	MCX	23
903-585J-71A	SMB	45	919-130P-51SX	MCX	23
903-586P-71A	Mini 75Ω SMB	51	919-131J-51SX	MCX	23

Catalog Index

Part Number	Series	Page	Part Number	Series	Page
919-136P-71A2X	MCX	24	AFB70-2	7/16	162
919-136P-71AX	MCX	24	AFB70-3	7/16	162
919-137P-71S2X	MCX	24	AFB70-4	7/16	161
919-137P-71SX	MCX	24	AFB7-4	7/16	161
930-100A-51S	Between Series Adapters	177, 178	AFB93-1	7/16	161
930-101A-51S	Between Series Adapters	177, 178	AFZ3-1	7/16	162
930-103P-51A	QMA	78	AFZ4-1	7/16	162
930-104P-51A	QMA	78	AFZ5-1	7/16	162
930-105J-51S	QMA	79	APH-BNCJ-TNCJ	Between Series Adapters	178, 179
930-106P-51A	QMA	78	APH-BNCJ-TNCP	Between Series Adapters	178, 179
930-108P-51S	QMA	78	APH-BNCP-FJ	Between Series Adapters	178
930-109J-51S	QMA	79	APH-BNCP-TNCJ	Between Series Adapters	178, 179
930-110P-51A	QMA	78	APH-BNCP-TNCP	Between Series Adapters	178, 179
930-111J-51P	QMA	79	APH-BNCP-UHFJ	Between Series Adapters	178, 179
930-115P-51S	QMA	78	APH-BNCP-UHFP	Between Series Adapters	178, 179
930-116J-51P	QMA	79	APH-MUHFP-UHFJ	Between Series Adapters	178, 179
930-118P-51A	QMA	78	APH-NJ-BNCJ	Between Series Adapters	178, 180
930-119P-51S	QMA	78	APH-NJ-BNCP	Between Series Adapters	178, 180
930-120P-51S	QMA	78	APH-NJ-FJ	Between Series Adapters	178, 180
930-121J-51S	QMA	78	APH-NJ-FP	Between Series Adapters	178, 180
930-122J-51S	QMA	78	APH-NJ-TNCJ	Between Series Adapters	179, 180
930-123J-51S	QMA	78	APH-NJ-TNCP	Between Series Adapters	179, 180
930-124J-51S	QMA	78	APH-NP-BNCJ	Between Series Adapters	178, 180
930-125J-51S	QMA	78	APH-NP-BNCP	Between Series Adapters	178, 180
930-128J-51P	QMA	79	APH-NP-TNCJ	Between Series Adapters	179, 180
930-129P-51S	QMA	78	APH-NP-TNCP	Between Series Adapters	179, 180
930-150P-51A	QMA	78	APH-NP-UHFJ	Between Series Adapters	179, 180
A-1JB	AMC	5	APH-SMAJ-BNCJ	Between Series Adapters	177, 178
A-1PA-113-100G2	AMC	5	APH-SMAJ-BNCP	Between Series Adapters	177, 178
A-1PA-113-125W2	AMC	5	APH-SMAJ-MCXJ	Between Series Adapters	176, 177
A-1PA-113-150B2	AMC	5	APH-SMAJ-MCXP	Between Series Adapters	176, 177
A-1PA-113-180B2	AMC	5	APH-SMAJ-MMCXJ	Between Series Adapters	176, 177
A-1PA-113-300B2	AMC	5	APH-SMAJ-MMCXP	Between Series Adapters	176, 177
A-1PA-132-100B2	AMC	5	APH-SMAJ-MUHFP	Between Series Adapters	177, 178
A-1PA-132-125G2	AMC	5	APH-SMAJ-MUHFP	Between Series Adapters	177, 178
A-1PA-132-150W2	AMC	5	APH-SMAJ-NJ	Between Series Adapters	177, 180
A-1PA-132-180B2	AMC	5	APH-SMAJ-NJBHD	Between Series Adapters	177, 180
A-1PA-132-300G2	AMC	5	APH-SMAJ-NP	Between Series Adapters	177, 180
A-1PA-137-100W2	AMC	5	APH-SMAJ-SMBJ	Between Series Adapters	176, 177
A-1PA-137-125B2	AMC	5	APH-SMAJ-SMBP	Between Series Adapters	176, 177
A-1PA-137-150G2	AMC	5	APH-SMAJ-TNCJ	Between Series Adapters	177, 179
A-1PA-137-180W2	AMC	5	APH-SMAJ-TNCP	Between Series Adapters	177, 179
A-1PA-137-300B2	AMC	5	APH-SMAJ-UHFJ	Between Series Adapters	177, 179
AFB133-1	7/16	161	APH-SMAJ-UHFP	Between Series Adapters	177, 179
AFB14	7/16	161	APH-SMAP-BNCJ	Between Series Adapters	177, 178
AFB15	7/16	161	APH-SMAP-BNCP	Between Series Adapters	177, 178
AFB16	7/16	161	APH-SMAP-MCXJ	Between Series Adapters	176, 177
AFB1-6	7/16	161	APH-SMAP-MCXP	Between Series Adapters	176, 177
AFB17	7/16	161	APH-SMAP-MMCXJ	Between Series Adapters	176, 177
AFB180-2	7/16	162	APH-SMAP-MMCXP	Between Series Adapters	176, 177
AFB20-1	7/16	161	APH-SMAP-MUHFP	Between Series Adapters	177, 178
AFB21-1	7/16	161	APH-SMAP-MUHFP	Between Series Adapters	177, 178
AFB2-9	7/16	161	APH-SMAP-NJ	Between Series Adapters	177, 180
AFB3-2	7/16	161	APH-SMAP-NP	Between Series Adapters	177, 180
AFB33-5	7/16	161	APH-SMAP-SMBJ	Between Series Adapters	176, 177
AFB4-2	7/16	161	APH-SMAP-SMBP	Between Series Adapters	176, 177
AFB42-14	7/16	162	APH-SMAP-TNCJ	Between Series Adapters	177, 179
AFB42-8	7/16	162	APH-SMAP-TNCP	Between Series Adapters	177, 179
AFB46-5	7/16	161	APH-SMAP-UHFJ	Between Series Adapters	177, 179
AFB5-4	7/16	161	APH-SMAP-UHFP	Between Series Adapters	177, 179
AFB6-1	7/16	161	CTL-1	Tools	186
AFB70-1	7/16	162	CTL-11	Tools	187

Part Number	Series	Page
CTL-13	Tools	188
CTL-14	Tools	188
CTL-15	Tools	188
CTL-2	Tools	186
CTL-3	Tools	186
CTL-4	Tools	186
CTL-5	Tools	186
CTL-6	Tools	186
CTL-8	Tools	186
CTL-9	Tools	187
PCTL-100	Tools	186
PCTL-1100	Tools	187
PCTL-1300	Tools	188
PCTL-200	Tools	187
PCTL-300	Tools	187
PCTL-400	Tools	187
PCTL-500	Tools	187
PCTL-600	Tools	187
PCTL-800	Tools	187
PCTL-900	Tools	187
SMP-FR-C06	SMP	10
SMP-FR-C07	SMP	10
SMP-FSBA-145	SMP	10
SMP-FSBA-224	SMP	10
SMP-FSBA-645	SMP	10
SMP-FSBA-990	SMP	10
SMP-FS-C06	SMP	10
SMP-FS-C07	SMP	10
SMP-MSFD-PCE	SMP	10
SMP-MSLD-PCR	SMP	10
SMP-MSLD-PCT	SMP	10
SMP-MSSB-PCR	SMP	10
SMP-MSSB-PCS	SMP	10
SMP-MSSB-PCT	SMP	10
Z1-1	Between Series Adapters	180
Z2-1	Between Series Adapters	180
Z7-1	Between Series Adapters	180