

Self-Adjusting Coax Strippers



2-Step Cable Stripper
 with self-adjusting replacement
 blades for RG-6, 58, 59 & 62.

Blister No.	Blades No.
24-7732P	99-7732B



3-Step Cable Stripper
 with self-adjusting replacement
 blades for RG-6, 58, 59 & 62.

Blister No.	Blades No.
24-7733P	99-7733B

3-Step Coax Strippers



3-Step Cable Stripper
 with adjustable replacement
 blades for standard & Teflon
 RG-58, 59 & 62.

Blister No.	Blades No.
24-7737P	99-7737



3-Step Cable Stripper
 with adjustable replacement
 blades for standard & Teflon
 RG-59, RG-6 & Belden 8281.


Blister No.	Blades No.
24-7738P	99-7738



3-Step Cable Stripper
 with non-adjustable replace-
 ment blades RG-8, 11 & 213.

Blister No.	Blades No.
24-7739P	99-7739

2-Step Coax Strippers



2-Step Cable Stripper
 with adjustable replacement
 blades for standard & Teflon
 RG-58, 59 & 62.

Blister No.	Blades No.
24-7735P	99-7735



2-Step Cable Stripper
 with adjustable replacement
 blades for standard & Teflon
 RG-59, RG-6 & Belden 8281.

Blister No.	Blades No.
24-7736P	99-7735



2-Step Cable Stripper
 with non-adjustable replace-
 ment blades RG-8, 11 & 213.

Blister No.	Blades No.
24-7731P	99-7731B



Universal 2-Step Cable Stripper
 with adjustable replacement
 blades for RG-6, 58, 59 & 62.

Blister No.	Blades No.
24-7734P	99-7734



2-Step Cable Stripper
 with adjustable replacement
 blades for RG-6, 58, 59 & 62.
 Poly bagged.

Part No.
VSCST-1B