

INDEX

Part Number	Page	Part Number	Page	Part Number	Page
ACA-Δ-0	77	(U)BJ41	37	(U)BJ224-RIA	28
ACC-Δ	77	(U)BJ46	37	BJ226GF	41
AD1	53	(U)BJ46GF	41	(U)BJ228	28
AD131	43	(U)BJ47	37	(U)BJ229	28
AD1300	43	(U)BJ48	36	(U)BJ246	37
ADAPTERS	64-67	(U)BJ48GF	41	BJ246GF	41
AD1W	53	(U)BJ49	37	(U)BJ249	37
AD1WHD	53	BJ50(FL)	47	BJ330	25
ADH1	53	BJ51(GL)	47	BJ331	25
ADH1W	53	BJ57	47	BJ338	25
ADMW12	53	BJ58(FL)	47	BJ339	25
(U)AD28	27	BJ59(FL)	47	BJ350	47
(U)AD228	27	BJ72(TL/FL)	7	BJ357	47
(U)AD48	36	BJ73(TL/FL)	7	BJ358	47
AD78 (TL/FL)	6	BJ74(TL/FL)	7	BJ359	47
(U)AD95	42	BJ74C	7	BJ372	7
AD158(FL)	20	BJ74C(TL/FL)	7	BJ373	7
(U)ADI95	42	BJ75(TL/FL)	7	BJ73HS	16
AD378	6	BJ76(TL/FL)	7	BJ374	7
AD3158	20	BJ77(TL/FL)	7	BJ374C	7
ADRMF70(TL/FL)	6	BJ77HS	16	BJ375	7
ADRMF370	6	BJ78(TL/FL)	7	BJ376	7
UADRMF220	27	BJ78HS	16	BJ376HS	16
ALP3	55	BJ79(TL/FL)	7	BJ377	7
APC3	55	BJ79C(TL/FL)	7	BJ378	7
APC(D)B-L	55	BJ79HS	16	BJ578HS	16
ALPL3	55	BJ80	24	BJ379	7
AVPC-L-50	55	BJ83	24	BJ379C	7
AVPCL-L-50	55	BJ89	24	BJ380	24
AVPCW-L-75	55	BJ89F	24	BJ383	24
AVPCLW-L-75	55	BJ92	43	BJ388	24
AT1	69	BJ95F	42	BJ389	24
AT2	69	(U)BJ95	42	BJ389F	24
AT4	69	(U)BJ96	42	BJ450	22
AWC	68	(U)BJ98-2	42	BJ457	22
AWS	68	(U)BJ120	38	BJ459AC	23
BCS	68	(U)BJ120SL	38	BJ770(GL)	7
BCS/C24T3E	68	(U)BJ120C	38	BJ803	24
BCS/C24T3E	68	BJ150(FL)	19	BJ833	24
(U)BJ20	28	BJ151	20	BJ88	24
(U)BJ20SL	28	BJ152(FL)	19	BJ883	24
(U)BJ21	28	BJ153(FL)	19	BJ893	24
(U)BJ23	28	BJ154(FL)	19	BJ893F	24
(U)BJ24	28	BJ154AC(FL)	19	BJ3150	19
(U)BJ26	28	BJ155(FL)	19	BJ3150HS	16
(U)BJ26GF	41	BJ157(FL)	19	BJ3150SHS	16
(U)BJ27	28	BJ157F(FL)	19	BJ3152	19
(U)BJ28	28	BJ157FLHS	16	BJ3153	19
(U)BJ28GF	41	BJ157HS	16	BJ3154	19
(U)BJ29	28	BJ158(FL)	19	BJ3154AC	19
BJ30	25	BJ159	18	BJ3155	19
BJ31	25	BJ159AC	18	BJ3157	19
BJ38	25	BJ159ACFL	18	BJ3157F	19
BJ39	25	BJ159FL	18	BJ3158	19
(U)BJ40	37	(U)BJ220	27	BJ3159	18
(U)BJ40SL	37	(U)BJ224	28	BJ3159AC	18

△ See Cable Group Table, pages 78-120. (U) = denotes 75 ohm version available. Call Factory for part numbers not listed.

INDEX

Part Number	Page	Part Number	Page	Part Number	Page
BJ3450	.22	DISTRIBUTION PANELS	.58	JSI - STANDARD	
BJ3457	.22	F CONNECTORS	43-45	INSULATED PANELS	.60
BJ3459AC	.23	GROUND FILTER	.41	JSIB - STANDARD INSULATED	
(U)BN23	.27	HOLE PLUGS	.57	PHENOLIC PANELS	.60
BN73(TL/FL)	.9	IMPEDANCE MATCHING		JS - MINIATURE	
BN83	.24	ADAPTER	.41	NON-INSULATED PANELS	.59
BN153(FL)	.20	MINI-WECO		JSI - MINIATURE	
BN373	.9	COAX PATCH JACKS	48, 49, 54, 56	INSULATED PANELS	.59
BN383	.24	STANDARD COAX		JSIX - MINIATURE INSULATED	
BN833	.24	PATCH JACKS	49-52, 55	PHENOLIC PANELS	.59
BN3153	.20	MINI-WECO		JSISM-60	.12
BNC Attenuator	.41	COAX PATCH PLUGS	.53	JSISM-120	.12
C24T2(A-U)	.68	STANDARD COAX		STANDARD COAX	
C24T3(A-U)	.68	PATCH PLUGS	.53	LOOPING PLUGS	.55
CRIMP DIES	.69	J11	.54	STANDARD TWINAX/TRIAX	
CD3-	.69	J11MW	.54	LOOPING PLUGS	.15
CD5-	.69	J11MWL	.54	SUBMINIATURE TWINAX/TRIAX	
STANDARD COAX		J11D	.54	LOOPING PLUGS	.15
CIRCUIT BOARD		J12	.54	MINI-BNC CONNECTORS	.35
JACKS	29-33	J13-R	.52	M22520/1-01	.70
MINIATURE COAX		J13C-R	.52	M22520/2-01	.70
CIRCUIT BOARD JACKS	34-37	J13WC-R	.52	M22520/5-01	.70
TWINAX/TRIAX CIRCUIT		J13H-R	.52	N CONNECTORS	42-43, 46
BOARD JACKS	6-8, 16, 20, 24-25	J13W-R	.52	(U)PL95	.42
(U)CJ20	.27	J13WH-R	.52	COAX PATCH	
(U)CJ40	.36	J14 SERIES	.50	CORDS	56-64
(U)CJ50	.47	J15 SERIES	.50	TWINAX/TRIAX PATCH	
CJ50FL	.47	J24WMSTHF-75	.50	CORDS	11-12, 14
CJ70(TL/FL)	.6	J70	.11		
CJ70C(TL/FL)	.6	J72	.11		
CJ80	.24	J72D	.11		
CJ150	.18	J72L	.12		
CJ150AC	.18	J72S	.11		
CJ150ACFL	.18	J72SM	.12		
CJ150FL	.18	J74-2T-R	.13		
(U)CJ220	.27	J74MST-R	.13		
(U)CJ240	.36	J74T-R	.13		
CJ350	.47	J94	.46		
CJ370	.6	(U)J95	.42		
CJ370C	.6	J150	.14		
CJ380	.24	J152(FL)	.14		
CJ450AC	.23	J158	.14		
CJ3150	.18	J308	.14		
CJ3150AC	.18	J3152	.14		
CJ3450AC	.23	HDVDP/HDVDPM SERIES	.48		
CRIMP TOOLS	.68	J315W SERIES	.49		
CT4L	.68	JS - STANDARD			
D HOLES	.60	NON-INSULATED PANELS	.60		
DIN CONNECTORS	39, 40				

For Part Numbers Not Listed
Call Factory

Visit Our Website:
www.EmersonConnectivity.com

△ See Cable Group Table, pages 78-120. "D" Mounting holes are on page 60. (U) = denotes 75 ohm version available.

INDEX

Part Number	Page	Part Number	Page	Part Number	Page
(U)PL20	.27	PL3155AC	.18	TROMPETER CABLE SPECS	.. 72-73
(U)PL21	.27	PL3455AC	.23	010-0043	.69
(U)PL21SL	.27	UPLFF220	.27	010-0044	.69
PL30	.25	PLPA330	.25	010-0045	.69
(U)PL40	.37	PLR74C	.6	010-0055	.69
(U)PL41	.37	PLR75C	.6	010-0070	.69
(U)PL41SL	.37	PLR75CFL	.6	010-0080	.69
PL50	.47	PLR155AC	.18	010-0088	.69
PL50C	.47	PLR155ACFL	.18	010-0096	.69
PL50FL	.47	UPLR220	.27	010-0097	.69
PL53	.47	PLR375C	.6	010-0098	.69
PL71	.11	PLR455AC	.22	010-0108	.52
PL71L	.12	PLR3155AC	.18	010-0123	.70
PL73	.6	PLR3455AC	.22	010-0133	.70
PL73C	.6	PARELLELING		105-1374	.69
PL74	.6	ADAPTERS	.51	105-1636	.69
PL74MC(FL)	.6	RFI CAPS, COAX	.63	105-1663	.69
PL74C	.8	RFI CAPS, TWINAX	.10	105-1885	.69
PL75	.6	REMOVAL TOOLS	.71	155-0830-1	.12
PL75C	.6	RT1L	.71		
PL75CFL	.6	RT1XL	.71		
PL75FL	.6	RT1S	.71		
PL75MC	.6	RT1SS	.71		
PL80	.24	RT4L	.71		
PL93	.46	RT4S	.71		
PL94	.46	RT5L	.71		
U(PL95)	.42	RT5S	.71		
(U)PL121	.39	RT5XL	.71		
(U)PL121SL	.39	RTC-1L	.71		
(U)PL122	.39	RTC-4L	.71		
(U)PL123	.39	RTR-1L	.71		
PL150	.10, 14, 66, 67	RTR-1XL	.71		
PL151	.20	SP450AC	.23		
PL153	.20	SPC8P-201	.17		
PL153AC	.20	SPC8S-201	.17		
PL155	.18	ST1	.68		
PL155FL	.18	STC-F	.68		
PL155AC	.18	STC-W	.68		
PL155ACFL	.18	TERMINATORS, COAX	.63		
(U)PL220	.27	TERMINATORS, TWINAX/TRIAX	.10		
(U)PL240	.37	TOOLS	.68-71		
PL330	.25				
PL350	.47				
PL375	.6				
PL375MC	.6				
PL375C	.6				
PL380	.24				
PL455AC	.23				
PL803	.24				
PL3155	.18				

For Part Numbers Not Listed
Call Factory

Visit Our Website:
www.EmersonConnectivity.com