

## TOOLS & ACCESSORIES

### CABLE ASSEMBLY TESTERS

#### Twinax/Triax Cable Assembly Tester



The Twinax/Triax Cable Assembly Tester is designed to test for opens, shorts, and cross wired connectors. The tester comes complete with terminators and testing instructions. This tool is designed to provide quick verification of TRB cable assemblies in the palm of your hands. The compact hand held unit measures 2<sup>3</sup>/<sub>4</sub>" x 4<sup>1</sup>/<sub>2</sub>" and provides versatility for testing connectors in the field. The unit comes in a soft zipper case which includes a 9v battery and terminators for standard TRB plugs. It can also be used for other connector families with an adapter, or short jumper cable when used with the proper termination.

**Twinax/Triax Cable Assembly Connector test set** **010-0123-1**

- 3 Conductors which test for opens, shorts, and cross connects
- Concentric TRB Interface, which tests both Twinax and Triax
- Pass/Open/Short LED indicators
- Easy to follow testing instructions
- Complete with terminators, carrying case, and a 9V battery.

#### BNC Coax Tester

Designed to test for the proper assembly of BNC plugs with coax cables. Tests for center contact pin height and continuity (short or open). The new BNC tester is the same size as the twinax/triax tester but exclusively tests only BNC plugs. Mini-WECO continuity test adapter now available (sold separately).

- Compact design
- Pass/Open/Short LED indicators
- One test required for testing remote cable runs
- Easy to follow instructions
- Complete with terminators, case, and 9V battery
- On/Off switch




#### Coax Cable Assembly Connector Test Set

75Ω BNC plug **010-0133**  
75Ω MBNC Plug **010-0208**

#### Mini-WECO Adapter (Continuity Only)

sold separately **105-1885**



#### Assembly Tools

Wrench Crimp	Type	D	E
<b>AT1</b>	BNC/N/TNC	.507	.445
<b>AT2</b>	TPS/TCM	.381	.318
<b>AT4</b>	TPS/TRS/TTM	See Drawing	